



KENMARK EYEWEAR

HOW TO CLEAN YOUR EYEWEAR

The Dish Soap Method

1. GATHER YOUR SUPPLIES



WASH YOUR HANDS FIRST!


Lotion-free Dish Soap
Microfiber Cloth
Warm Water (not too hot!)
Your Frames

2. RINSE



With clean hands, rinse your frames underneath a stream of lukewarm water to remove any debris or dust.

3. APPLY DISH SOAP




Apply a small drop of lotion-free dish soap to each lens and gently rub it in using clean fingertips, extending to the nosepads and temples.

4. RINSE AGAIN



Completely rinse frames in lukewarm water, leaving no traces of soap behind.

5. DRY



Gently dry off the frames using a soft microfiber cloth and enjoy your freshly cleaned frames!

Disclaimer

The above information is provided for reference purposes only and does not constitute health, safety, or medical advice. If you have health, safety, or medical concerns about the spreading and/or contracting of infectious diseases associated with wearing or disposing of eyewear frames, please consult your physician or the Centers for Disease Control and Prevention at www.cdc.gov for the most recent developments and advice. Kenmark Eyewear makes no assurance or warranty of the accuracy or effectiveness of the above information and assumes no obligation or liability related to the above information.



KENMARK EYEWEAR

HOW TO CLEAN YOUR EYEWEAR

The Alcohol Method

1. GATHER YOUR SUPPLIES



WASH YOUR HANDS FIRST!

- Rubbing Alcohol (at least 70% isopropyl alcohol)
- Spray Bottle
- Microfiber Cloth
- Your Frames

2. DILUTE THE ALCOHOL



Fill your spray bottle ¼ full of rubbing alcohol and fill the remainder of the bottle with water. Gently shake the mixture.

3. SPRAY FRAMES



Spray frames with the mixture, coating them completely. Make sure to get the nose pads and temples, too!

4. WIPE CLEAN



Wipe clean with a microfiber cloth and enjoy your freshly cleaned frames!

What Not To Do



DO NOT USE HOT WATER

It can warp your frames

DO NOT USE DISH SOAP WITH ADDITIVES LIKE LOTION

DO NOT USE ABRASIVE CHEMICALS LIKE ACETONE OR AMMONIA

It can strip off any lens coatings

DO NOT USE PAPER TOWELS

It can scratch your lenses

DO NOT FOG YOUR LENSES WITH YOUR BREATH BEFORE WIPING

It promotes the spread of germs

DO NOT USE THE DISH SOAP METHOD FOR WOOD FRAMES

The water will warp them!

DO NOT USE YOUR SHIRT TAIL TO DRY YOUR FRAMES

It can scratch your lenses

Pro Tips!



WHEN NOT IN USE KEEP EYEWEAR STORED AWAY IN YOUR CASE

A hard shell case is preferred!

DON'T FORGET TO GET THE NOOKS & CRANNIES!

Nose pads and earpieces are commonly overlooked.

MAKE SURE YOUR MICROFIBER CLOTH IS REGULARLY CLEANED

Your freshly cleaned eyewear is back to square one if you're using a dirty cloth to wipe it dry!